

Step 1 unzip all 3 zippers

Step 2 open two snaps on each side at waistband



Step 3 fold down front to to knees to more easily access adult brief or bag

